

ProXRT Battery / Charging

The GPS Pathfinder ProXRT receiver uses an internal rechargeable Lithium-ion battery, which typically provides 13 hours of operation time. The operational time provided by the internal battery depends on the type of measurement and operating conditions.

Charging the Battery:

1. Connect the 26-pin end of the multiport adaptor to the 26-pin plug on the receiver.
2. Plug the barrel end of the AC adapter cord into the other end of the multiport adaptor.
3. Connect the AC power cord to the AC adapter.
4. Plug the AC power cord into an electrical outlet.



External Power Note – The life of the battery can be significantly shortened if power is constantly supplied to the receiver. To avoid this issue, connect the receiver to an external power source only when the battery requires charging. Once fully charged, disconnect the external power source and allow the battery to discharge through normal use.

General Note – The supported GPS field software does not turn on or turn off the GPS Pathfinder ProXRT receiver when connecting or disconnecting to the receiver. Remember to turn off the receiver to save battery power when you disconnect from the receiver or close the GPS field software.